

Important CarProg hardware modifications

Don't forget to make these 4 CarProg hardware modifications:

1. Open CarProg and change resistor marked 2R2 to resistor 0R0 or simple bridge like in picture. This hardware modification will improve external power current checking (message "external power consumption is more than 500mA):



2. Add two 1kOm resistors like in picture. This hardware modification will improve M35080 EEPROM in-circuit programming:



Add 2 resistors (1kOm) like in picture

3. With wire short 2 points on CarProg board like in picture. This hardware is necessary for Opel ECU tool owners – some ECU will not work by K-line without this update:

